


Astro 2 – Three speed

CROSS REFERENCE CHART



| Models | B&G | Grundfos | Wilco | Taco | Speed | Armstrong | |
|------------------|--------------|--|--|---|---|-------------------------|------------------|
| Stainless Steel | | UP 15-10 BUC5 [^] , UP 15-10 B5 [^] , UP 15-10 B7 ^{^^} | Star 3 BS 5 [^] , Star 3 BS 7 ^{^^} | 003-BC4-I, 003-B4-2-IFC, 003-BC4 [^] , 003-B4 ^{^^} | ➔ 1 | Astro 220SSU | |
| | | UP 15-10 F/FR [*] , UP 15-10 BUC7 ^{^^} | Star 5 BU | | ➔ 2 | | |
| | | UP 15-10 F/FR [*] , UP 15-10 BUC7 ^{^^} | Star 5 BU | | ➔ 3 | | |
| | | NBF-9U/LW, SSF-9U/LW NBF-18S [^] | UPS 15-35SUC S2 | | | ➔ 1 | Astro 225SSU |
| | | | UP 15-29SU | | 006-BC4-I, 006-B7-IFC | ➔ 2 | |
| | | NBF-12U/LW SSF-12U/LW | UP 15-35SUC, UPS 15-35SUC S3 UP 15-18BUC 5/7 [*] | Star 11 BU | | ➔ 3 | |
| | | NBF-12F/LW | UPS 15-35SFC S3 ^{**} | Star S 16BFX S2 | 005-BF2/-I-IFC, 005-SF2/-IFC 007-BF5/-I-IFC, 007-SF5/-IFC, 008-BC6, 008-BC6-IFC ^{**} 008-SF6/-IFC | ➔ 1 | Astro 230SS |
| | | SSF-22, NBF-22 | UP 15-42SF ^{**} UP 15-64SF ^{**} | Star S 16BFX S3 Star 16BFX | 00R-SF6-IFC | ➔ 2 | |
| | | NBF-25 S1 | UPS 15-55SFC S1 ^{**} | Star S 21BFX S1 | | ➔ 3 | |
| | | NBF-25 S2 | UPS 15-55SFC S2 ^{**} | Star S 21BFX S2 | | ➔ 1 | Astro 250SS |
| | | NBF-25 S3 | UPS 15-55SFC S3 ^{**} | Star S 21BFX S3 Star 21BFX | | ➔ 2 | |
| | | NBF - 8S/LW | | | | ➔ 3 | |
| Lead Free Bronze | NBF - 10S/LW | UP 15-18B5 | Star 8 BS 5 | 006-BC4 | ➔ 1 | Astro 225BS 1/2" SWT | |
| | | | | | ➔ 2 | | |
| | | UP 15-18B7 | Star 8 BS 7 | 006-B4 | ➔ 3 | | |
| Cast Iron | NRF-9F/LW | UPS 15-42FR S1, UPS 15-58FRC S1 UP 15-10FR | Star S 16FX S1 | 005-F2, 005-F2-IFC | ➔ 1 | Astro 230CI | |
| | | UPS 15-42FR S2, UPS 15-58FRC S2 | Star S 16FX S2 | 007-F5/-7-IFC, 008-F6 | ➔ 2 | | |
| | NRF-22 | UP 15-42FR, UPS 15-42FR S3 UPS 15-58FRC S3 | Star S 16FX S3 Star 16FX | | ➔ 3 | | |
| | | UPS 15-42F S1, UPS 15-58FC S1 UP 15-10F | Star S 16F S1 | 005-F2-3-IFC, 006-F4, 006-F7-IFC | ➔ 1 | Astro 230CI-R | |
| | | UPS 15-42F S2, UPS 15-58FC S2 | Star S 16F S2 | 007-F5-5/-8-IFC, 008-F6-I-IFC 00R-F6 IFC | ➔ 2 | | |
| | | UP 15-42F, UPS 15-42F S3 UPS 15-58FC S3 | Star S 16F S3 Star 16F | 00R-F6-I-IFC | ➔ 3 | | |
| | | | | Star S 21FX S1 | 00R-MSFI-IFC S1 | ➔ 1 | Astro 250CI |
| | | | | Star S 21FX S2 | 00R-MSFI-IFC S2 | ➔ 2 | |
| | | | | Star S 21FX S3 Star 21FX | 00R-MSFI-IFC S3 | ➔ 3 | |
| | | NRF-25 S1 | | Star S 21F S1 | 00R-MSFI-I-IFC S1 | ➔ 1 | Astro 250CI-R |
| | | NRF-25 S2 | | Star S 21F S2 | 00R-MSFI-I-IFC S2 | ➔ 2 | |
| | | NRF-25 S3 NRF-36 S1 | | Star S 21F S3 Star 21F | 00R-MSFI-I IFC-S3 | ➔ 3 | |

Note: * Dimension & connection may vary.
 ** Flange orientation may vary.
 ^ Connection with 1/2" sweat adaptor(s).
 ^^ Connection with 3/4" sweat adaptor(s).

S. A. Armstrong Limited
 23 Bertrand Avenue
 Toronto, Ontario
 Canada, M1L 2P3
 T: (416) 755-2291
 F (Main): (416) 759-9101

Armstrong Pumps Inc.
 93 East Avenue
 North Tonawanda, New York
 U.S.A. 14120-6594
 T: (716) 693-8813
 F: (716) 693-8970

Armstrong Integrated Limited
 Wenlock Way
 Manchester
 United Kingdom, M12 5JL
 T: +44 (0) 8444 145 145
 F: +44 (0) 8444 145 146

